

## Connect to a Computer

# Quick Installation Guide



Insert the adapter into your computer by following these steps:

- a. Turn off your computer, unplug the power cord and other connected peripheral devices to your computer.
- b. Remove the case panel. Locate an available PCI-E slot and remove its slot cover
- c. Carefully insert the adapter into the PCI-E slot and secure it with the retaining screw.
- d. Replace the case panel.
- e. Reconnect the power cord and turn on your computer.


#### Note:

In Windows XP a Found New Hardware Wizard window will appear when the adapter is detected. Please click Cancel.

# 2 Install Driver and Utility

You can also download the driver and utility at www.tp-link.com.

- Insert the CD and run the **Autorun.exe** from the pop-up Autoplay window.
  - Note: In some operating systems, the CD screen will pop up automatically. Otherwise, run the CD manually.
- b. Select TL-WN781ND and click Install Driver and Utility, then follow the InstallShield Wizard to



complete the installation.

TL-WN722N

TL-WN781ND

Install Driver and Utility

● Browse CD ■ EXIT

TL-WN721N

### Join a Wireless Network

For Windows 10, TP-LINK Utility is not supported, please use the Windows built-in Wireless Utility to join a network.

### Option 1: Via TP-LINK Utility

Select your Wi-Fi network from the pop-up utility window and click **Connect**. The symbol indicates a successful connection



### Option 2: Via Windows Wireless Utility

Click (Network icon) on the system tray, select your Wi-Fi network, and click **Connect**.

Note: In Windows XP, you need to close the TP-LINK Utility before using the Windows Wireless Utility.





