TP-LINK®
The Reliable Choice

EAC

Quick Installation Guide

 For Mac OS X

AC1300 Wireless Dual Band USB Adapter
MODEL NO. Archer T4U
7106506736 REV5.1.0

1 Connect to a Computer

Option 1: Directly

Option 2: Via the USB Extension Cable

2 Install Driver and Utility

a. Insert the CD.
   Note:
   You can also download the driver and utility at
   http://www.tp-link.com.

b. Browse the CD, go to **Archer T4U** > **Mac OS X Driver**, unzip the **Mac OS X** *version*.**zip** file and run the Installer.

c. Follow the wizard to complete the installation.

Installer.pkg   uninstall.command   SHELL

3 Join a Wireless Network

Option 1: Via TP-LINK Utility

a. Click 🖱 (TP-LINK Wireless Configuration Utility) on the menu bar.

b. Select your Wi-Fi network and enter the Wi-Fi password when prompted.

Option 2: Via Wi-Fi Protected Setup (WPS)

a. Press the WPS button on your router.

b. Within 2 minutes, press and hold the WPS button on the adapter until the configuring screen appears.


c. When you are prompted "WPS Protocol Finished", click **OK**.

For Windows

1 Connect to a Computer

Option 1: Directly

Option 2: Via the USB Extension Cable

Note:
In Windows XP, a **Found New Hardware Wizard** window will appear when the adapter is detected. Please click **Cancel**.

This USB Adapter can be powered only by computers that comply with Limited Power Source (LPS).

2 Install Driver and Utility

a. Insert the CD and run the **Autorun.exe** from the pop-up Autoplay window.

Notes:
1. You can also download the driver and utility at **http://www.tp-link.com**.
2. In some operating systems, the CD screen will pop up automatically. Otherwise, run the CD manually.

b. Select **Archer T4U** and click **Install Driver**, then follow the InstallShield Wizard to complete the installation.

Note:
During the installation, select **TP-LINK Wireless Configuration Utility and Driver** if you want to use TP-LINK Utility and WPS function.

TP-LINK   Setup Wizard

Archer T4U
Install Driver
User Guide

⊕ Browse CD   ⊕ EXIT

3 Join a Wireless Network

Option 1: Via Windows Wireless Utility

Click 📶 or 📶 (Network icon) on the taskbar, select your Wi-Fi network, and click **Connect**.

Note:
In Windows XP, if you have installed TP-LINK Utility, you need to switch to Windows wireless configuration tool first.

Networks	
Wi-Fi	
TP-LINK_TEST_Device	📶
TP-LINK_0903	🔒 📶
TP-LINK_XXXX	🔒 📶
☑ Connect automatically	Connect

Option 2: Via TP-LINK Utility

Select your Wi-Fi network from the pop-up utility window and click **Connect**. The symbol 📶 indicates a successful connection.

TP-LINK				×
Status	WPS	Network	Profile	Advanced

Network Name(SSID)	Security	Channel	Signal
TP-LINK_XXXX	WPA/WPA2-Personal	6 (2.4G)	
☐ Connect automatically		Connect	
TP-LINK_0903	🔒 WPA/WPA2-Personal	2 (2.4G)	
TP-LINK_TEST_Device	None	36 (5G)	
TP-LINK_0001	None	5 (2.4G)	

Network

📶 TP-LINK_X

TP-LINK

Option 3: Via Wi-Fi Protected Setup (WPS)

a. Press the WPS button on your router.

b. Within 2 minutes, press and hold the WPS button on the adapter until the configuring screen appears.

WPS

c. When you are prompted "Successfully connected to the network by WPS!", click **OK**.

For more information, please visit our website
http://www.tp-link.com
©2016 TP-LINK